MA188 FM Transmitter/MP3 Player Instruction Manual

1. Insert the MA188 into your vehicle's 12V power outlet (in some vehicles this is the cigarette lighter)
2. Connect your USB thumb drive or MP3 player to the unit's USB jack (see picture below).
3. Press and release the **►/ II** (play/pause) key, and the **"POWER"** light will then flash. This means the unit is on and you can now play music through the unit.
4. Press and release the **►/ II** key again and the **"POWER"** light will remain on (solid) – this means the unit is now paused.
5. Press the **I◄◄** key and hold to increase the volume; and press it and release to return to the last song. Press **►►I** key and hold to decrease the volume; press and release it to skip to the next song.
6. To change the FM station that the unit transmits on: Press the "**F"** key for three seconds, the "**FM Light"** will start to flash indicating which transmitting station you are on. Repeatedly press the **"F"** key to change to the next transmitting station. When the last station has been reached, the unit will start back again at the first station.
7. There are 7 transmitting stations: FM87.7, FM87.9 FM88.1, FM88.3, FM88.5, FM88.7 and FM88.9.

PUT UNIT DRAWING HERE

nextar®